Horizon Digital Combination Locks

Play Instructional Video 🕑

		MOD	E				
FUNCTION	PUBLIC	PRIVATE	Mille	KEY SEQUENCE			NOTES
MASTER CODE FUNCTIONS - FO	R ST	EPS	1-3	PLEASE ENTER THE R	RELEVA	NT NUMBERS IN THE SEQUENCE	SHOWN BELOW (EG. STEP1STEP2STEP3)
				STEP 1	STEP 2	STEP 3	
CHANGE MASTER CODE	1	1	1	[logo] [Old Master Code]	01	[New Master Code] [New Master Code]	MASTER CODE IS EIGHT DIGITS
SET / CHANGE SUB-MASTER CODE	1	1	1	[logo] [Master Code]	03	[New Sub-Master Code]	SUB-MASTER CODE IS SIX DIGITS
DELETE SUB-MASTER CODE	1	1	1	[logo] [Master Code]	07		DELETES SUB-MASTER CODE
SET / CHANGE TECHNICIAN CODE	1			[logo] [Master Code]	10	[New Technician Code]	TECHNICIAN CODE IS SIX DIGITS
DELETE TECHNICIAN MODE	1			[logo] [Master Code]	11		DELETES TECHNICIAN CODE
CHANGE USER CODE		1		[logo] [Master Code]	02	[New User Code]	USER CODE IS FOUR OR SIX DIGITS
SET SINGLE USER PRIVATE MODE - FOUR DIGIT CODE	1		1	[logo] [Master Code]	09	[New Four Digit User Code]	SETS LOCK INTO FOUR DIGIT PRIVATE MODE - SINGLE USER ACCESS
SET MULTI-USER PRIVATE MODE (SIX DIGIT CODES)	1	1		[logo] [Master Code]			SETS LOCK INTO MULTI-USER MODE - NO USERS ARE ACTIVE INITIALLY
SET PUBLIC MODE - FOUR DIGIT CODE		1	1	[logo] [Master Code]	08		SETS LOCK INTO FOUR DIGIT PUBLIC MODE
SET AUDIBLE BUTTONS ON	1	1	1	[logo] [Master Code]	12		LOCK WILL BEEP ON EACH BUTTON PRESS
SET AUDIBLE BUTTONS OFF	1	1	1	[logo] [Master Code]	13		LOCK WILL OPERATE SILENTLY
SET UNSUCCESSFUL CODE LOCKOUT ON	1	1	1	[logo] [Master Code]	24		KEYPAD IS DISABLED FOR A SHORT TIME FOLLOWING FIVE INCORRECT ENTRY ATTEMPTS
SET UNSUCCESSFUL CODE LOCKOUT OFF	1	1	1	[logo] [Master Code]	25		KEYPAD DISABLE IS TURNED OFF
SET TIMER AUTO-UNLOCK ON & SET TIME	1			[logo] [Master Code]	16	[3 Digit Time Code]	AUTOMATICALLY OPENS LOCK AFTER SET TIME PERIOR SEE NOTES ON TIMERS BELOW.
SET TIMER AUTO-UNLOCK OFF	1			[logo] [Master Code]	17		UNIT WILL NO LONGER OPEN AUTOMATICALLY
SET AUTO-TIMED CODE CANCEL ON & SET TIME	1			[logo] [Master Code]	26	[3 Digit Time Code]	DISABLES USER CODE AFTER SET TIME PERIOD. SEE NOTES ON TIMERS BELOW.
SET AUTO-TIMED CODE CANCEL OFF	1			[logo] [Master Code]	27		UNIT WILL NO LONGER CANCEL USER CODE
SET RAS MODE	1	1	1	[logo] [Master Code]	20	[Serial Number]	REMOTE ALLOCATION SYSTEM - CAN ONLY BE USED WITH ON-LINE SOFTWARE
SET SINGLE USE RAS MODE	1	1	1	[logo] [Master Code]	22	[Serial Number]	REMOTE ALLOCATION SYSTEM - CAN ONLY BE USED WITH ON-LINE SOFTWARE
RE-LOCK TIME		1		[logo] [Master Code]	23	[Enter chosen time length]	1 = 8 SECONDS, 2 = 16 SECONDS, 3 = 32 SECONDS 4= 40 SECONDS, 5= 50 SECONDS, 6= 60 SECONDS
OPEN LOCK AND DELETE USER CODE	1			[Master Code]			MASTER CODE IS EIGHT DIGITS
OPEN LOCK		1	1	[Master Code]			MASTER CODE IS EIGHT DIGITS
CLOSE LOCK		1	1				PUSH HANDLE BACK INTO UNIT





Horizon Digital Combination Locks

Play Instructional Video 🕑

FUNCTION	PUBLIC	MOD		KEY SEQUENCE			NOTES		
	Snp.	PRIVATE	ny lie						
SUB-MASTER CODE FUNCTIONS									
CHANGE SUB-MASTER CODE	1	1	1	[logo] [Sub-Master Code]	03	[New Sub-Master Code] [New Sub-Master Code]	SUB-MASTER CODE IS SIX DIGITS		
CHANGE USER CODE		1		[logo] [Sub-Master Code]	02	[New User Code]	USER CODE IS FOUR DIGITS		
OPEN LOCK AND DELETE USER CODE	1			[Sub-Master Code]			SUB-MASTER CODE IS SIX DIGITS.		
OPEN LOCK		1	1	[Sub-Master Code]			SUB-MASTER CODE IS SIX DIGITS.		
CLOSE LOCK		1	1				PUSH HANDLE BACK INTO UNIT		
TECHNICIAN CODE FUNCTIONS									
OPEN LOCK AND RETAIN USER CODE	1			[Technician Code]			TECHNICIAN CODE IS SIX DIGITS		
OPEN LOCK		1	1	[Technician Code]			TECHNICIAN CODE IS SIX DIGITS		
CLOSE LOCK	1	1	1				PUSH HANDLE BACK INTO UNIT		
USER CODE FUNCTIONS									
CHANGE USER CODE		1		[logo] [User Code]	02	[New User Code] [New User Code]	USER CODE IS FOUR DIGITS		
OPEN LOCK	1	1		[User Code]			USER CODE IS FOUR DIGITS		
OPEN LOCK			1	[Access Code]			ACCESS CODE IS TWO DIGIT USER REFERENCE FOLLOWED BY FOUR DIGIT USER CODE		
CLOSE LOCK	1			[User Code] [User Code]			WHEN DOUBLE USER CODE ENTRY MODE IS SET		
CLOSE LOCK		1	1				PUSH HANDLE BACK INTO UNIT		
FUNCTIONS REQUIRING NO AUTHORISATION									
BATTERY CHECK	1		1	[logo] [logo]			REPLACE BATTERIES IF RED LIGHT SHOWS		

NOTES	TIMER FUNCTIONS		TIME CODE EXAMPLES
	TIME CODE	001	1 MIN
	TIME CODE	010	10 MINS
	TIME CODE	030	1/2 HR
	TIME CODE	060	1 HR
	TIME CODE	480	8 HRS
	TIME CODE	720	12 HRS
	TIME CODE	999	16 HRS 39 MINS (MAXIMUM)
	ALL TIMES ARE APPROXIMATE +/- 10%		

LOWE & FLETCHER LTD

Moorcroft Drive, Wednesbury, West Midlands, WS10 7DE, UK Tel: +44 (0) 121 505 0400 Email: sales@lowe-and-fletcher.co.uk www.lowe-and-fletcher.co.uk

LOWE & FLETCHER, INC.

650 Airport Place, Norton Shores, MI-49441, Michigan, USA Tel: +1 (616) 994 0490 Email: sales@loweandfletcherinc.com www.loweandfletcherinc.com

EURO-LOCKS SA NV

Rue de la Fontaine 8, 6600 Bastogne, Belgium Tel: +32 61 212 261 Email: sales@euro-locks.be www.euro-locks.be

EURO-LOCKS SA

1 Rue du Stade, 57730 Folschviller, France Tel: +33 (0) 3 87 92 6111 Email: euro-locks@euro-locks.fr www.euro-locks.fr

EURO-LOCKS GMBH

Am Bruchwald 22, 66280 Sulzbach/Neuweiler, Germany Tel: +49 (0) 6897 9072 0 Email: vertrieb@euro-locks.de www.euro-locks.de

EURO-LOCKS SP. Z O.O.

ul. Pawła 29, 41-708 Ruda Śląska, Poland Tel: +48 (32) 344-78-70, -82, -84 Email: sekretariat@euro-locks.pl www.euro-locks.pl