

# A286 User Instructions




## Combination Lock A286

### Setting your personal combination

#### Step 1

To open, enter the factory code 3333 and turn the knob clockwise to OPEN.

The code auto-scrambles to 0000.



#### Step 2


Enter the factory code 3333 again to be able to bring the button to the C position.

Enter the individually selected code in the C position.



#### Step 3

Slowly turn the knob to CLOSE, during this process the code auto-scrambles to 0000, your code is now saved.




**Note:** If you forget your code, please contact the person responsible for the locker installation.

### Code finding/Emergency opening

#### Step 1

Insert the key into the CLOSE position and slowly turn anti-clockwise until it stops.



#### Step 2

Slowly turn the knob to OPEN (a slight clacking can be heard), the currently stored numerical code is displayed automatically.

If the 4 numbers are not exactly centred in a row, repeat this procedure.



#### Step 3

Turn the key back and remove it.

**Note:** The master key should only be used for emergency access.

#### Lowe & Fletcher Ltd (UK)

E: sales@lowe-and-fletcher.co.uk

T: +44 (0) 121 505 0400

#### Lowe & Fletcher Inc (USA)

E: sales@loweandfletcherinc.com

T: +44 (0) 121 505 0400

#### Euro-Locks SA (France)

E: euro-locks@euro-locks.fr

T: +33 (0)3.87.92.61.11

#### Euro-Locks SA NV (Belgium)

E: sales@euro-locks.be

T: +32 61 212.261

#### Euro-Locks Sicherheitseinrichtungen GmbH (Germany)

E: vertrieb@euro-locks.de

T: +49 (0) 6897 9072 0

#### Euro-Locks Sp. z o. o. (Poland)

E: sekretariat@euro-locks.pl

T: +48 (32) 344-78-70, -82, -84